


Installation Guide

Wireless OMS 868.95 MHz module with 2 pulse inputs


1.




2.




3.




4.




5.




6.



7.



8.



Danfoss A/S

Energy Meters • Ulvehavevej 61 • DK-7100 Vejle • Denmark

Phone: +45 7488 8500 • Fax: +45 7488 8501

heating@danfoss.com • www.heating.danfoss.com